

MELSEC A Series

Programmable Controller

User's Manual

AJ71LP21/AJ71BR11 Network Module

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Oct., 1993	IB (NA) 66444-A	First edition

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end User.

CONTENTS

1. GENERAL DESCRIPTION	1-1
2. PERFORMANCE SPECIFICATIONS	2-1 ~ 2-2
3. PART NAMES AND SETTINGS	3-1 ~ 3-7
3.1 Names and Applications of AJ71LP21 Parts	3-1 ~ 3-3
3.2 Names and Applications of AJ71BR11 Parts	3-4 ~ 3-6
3.3 Cautions on Configuring a Network System	3-7
3.3.1 Installation positions of AJ71LP21/AJ71BR11	3-7
3.3.2 Cautions on building a coaxial bus system	3-7
4. DIMENSIONS	4-1 ~ 4-2
4.1 AJ71LP21	4-1
4.2 AJ71BR11	4-2

1. GENERAL DESCRIPTION

This manual covers the specifications and part names for the AJ71LP21 and AJ71BR11 network modules for use in a MELSEC-A series MELSECNET/10 network system.

AJ71LP21	Network module for optical loop system
AJ71BR11	Network module for coaxial cable system

For detailed information on the MELSECNET/10 network system, refer to the MELSECNET/10 Network System Reference Manual (PC-to-PC networks).

2. PERFORMANCE SPECIFICATIONS

MELSEC-A

2. PERFORMANCE SPECIFICATIONS

The performance specifications for the AJ71LP21/AJ71BR11 modules are presented below.

Item	AJ71LP21		AJ71BR11	
	Max. number of link points per network	LX/LY	8192 points	
LB		8192 points		
LW		8192 points		
Max. number of link points per station	$\frac{B+Y}{8} + 2 \times W \leq 2000$ bytes			
Communication speed	20 MBPS (multiplex transmission)/10 MBPS		10 MBPS	
Communication method	Token ring method		Token bus method	
Synchronous method	Frame synchronous method			
Transmission path method	Duplex loop		Simplex loop	
Overall extension distance	30 km (18.6 miles) (When SI cable is used: 500 m (0.31 mile) between stations) (When QSI cable is used: 1 km (0.62 mile) between stations)		3C-2V	5C-2V
			300 m (0.2 mile) 300 m (0.2 mile) between stations	500 m (0.31 mile) 500 m (0.31 mile) between stations
Max. number of networks	255			
Max. number of groups	9			
Number of connecting stations	64 stations (1 control station, 63 normal stations)		32 stations (1 control station, 31 normal stations)	
Max. number of modules per CPU	AnUCPU : 4 Other than AnUCPU : 1			
Coding system	NRZI code (Non Return to Zero Inverted)		Manchester code	
Transmission format	Conforms to HDLC (frame method)			
Error control system	CRC (generating polynomial $X^{16} + X^{12} + X^5 + 1$) and retry after time-out			
RAS function	<ul style="list-style-type: none"> • Loopback function in the event of error detection or cable break (AJ71LP21 only) • Diagnosis function for self station link line check • Prevention of system "down" through control station shift function • Error detection by special relays and registers • Network monitoring and various diagnosis functions 			
Transient transmission	<ul style="list-style-type: none"> • N : N communication (Monitoring, uploading/downloading of programs etc.) • ZNRD/ZNWR instruction (N : N) 			
Connecting cable	SI-200/250	QSI-185/230	3C-2V, 5C-2V or equivalent	
Applicable connector	2-core optical connector plug CA9003	2-core optical connector plug CA7003	BNC-P-3-Ni-CAU BNC-P-5-Ni-CAU (DDK) or equivalent	
Cable transmission loss	12 dBm/km max.	5.5 dBm/km max.	Conforms to *JIS C 3501	

2. PERFORMANCE SPECIFICATIONS

MELSEC-A

Item	AJ71LP21	AJ71BR11
Current consumption (DC 5V)	0.65 A	0.8 A
Weight	0.45 kg (0.99 lb)	
Number of occupied I/O points	32 points	


For general specifications, refer to the manuals on the programmable controller CPUs used in the network system.

*: JIS: Japanese Industrial Standard

3. PART NAMES AND SETTINGS

The names of the parts of the AJ71LP21 and AJ71BR11 modules and their applications are described below.




3.1 Names and Applications of AJ71LP21 Parts



No.	Name	Contents																																														
(1)	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>AJ71LP21</p> <table style="font-size: small; border-collapse: collapse;"> <tr><td>RUN</td><td>—</td><td>POWER</td></tr> <tr><td>PC</td><td>—</td><td>MNG</td></tr> <tr><td>REMOTE</td><td>—</td><td>S.MNG</td></tr> <tr><td>DUAL</td><td>—</td><td>D.LINK</td></tr> <tr><td>SW.E</td><td>—</td><td>T.PASS</td></tr> <tr><td>M/S.E</td><td>—</td><td>CPU R/W</td></tr> <tr><td>PRM.E</td><td>—</td><td>ORC</td></tr> <tr><td>OVER</td><td>—</td><td>AB IF</td></tr> <tr><td>TIME</td><td>—</td><td>TIME</td></tr> <tr><td>DATA</td><td>—</td><td>DATA</td></tr> <tr><td>UNDER</td><td>—</td><td>UNDER</td></tr> <tr><td>LOOP</td><td>—</td><td>LOOP</td></tr> <tr><td>SD</td><td>—</td><td>SD</td></tr> <tr><td>RD</td><td>—</td><td>RD</td></tr> <tr><td>F.LOOP</td><td></td><td>R.LOOP</td></tr> </table> </div>	RUN	—	POWER	PC	—	MNG	REMOTE	—	S.MNG	DUAL	—	D.LINK	SW.E	—	T.PASS	M/S.E	—	CPU R/W	PRM.E	—	ORC	OVER	—	AB IF	TIME	—	TIME	DATA	—	DATA	UNDER	—	UNDER	LOOP	—	LOOP	SD	—	SD	RD	—	RD	F.LOOP		R.LOOP	RUN	Lit when the module is running normally. Off when a WDT error or SP.UNIT ERROR occurs.
		RUN	—	POWER																																												
		PC	—	MNG																																												
		REMOTE	—	S.MNG																																												
		DUAL	—	D.LINK																																												
		SW.E	—	T.PASS																																												
		M/S.E	—	CPU R/W																																												
		PRM.E	—	ORC																																												
		OVER	—	AB IF																																												
		TIME	—	TIME																																												
		DATA	—	DATA																																												
		UNDER	—	UNDER																																												
		LOOP	—	LOOP																																												
		SD	—	SD																																												
RD	—	RD																																														
F.LOOP		R.LOOP																																														
PC	Lit when "PC-to-PC network" is set (SW1 setting = OFF).																																															
REMOTE	Lit when "remote I/O network" is set (SW1 setting = ON).																																															
DUAL	Lit when multiplex transmission is effective.																																															
SW.E	Lit when there is an error in switch settings (2) to (6).																																															
M/S.E	Lit if a station number is duplicated, or there is more than one control station, in the same network.																																															
PRM.E	Lit on occurrence of a common parameters/station specific parameters matching error, or if the parameters received from the subcontrol station differ from those that the self station received from the control station.																																															
POWER	Lit while power is supplied to the module.																																															
MNG	Lit when the module is set as a control station. Off when the module is set as a normal station.																																															
S.MNG	Lights when the module becomes a sub-control station.																																															
D.LINK	Lit while data link operation is in progress.																																															
T.PASS	Lit when the module participates in a baton pass.																																															
CPU R/W	Lit during communication with the CPU.																																															



3. PART NAMES AND SETTINGS

MELSEC-A

No.	Name	Contents	
(1)	LED	CRC	Lit if an error is discovered in the receive data code check. <Cause> Timing in which the station sending data to the relevant station goes noncontact, hardware fault, cable fault, noise, etc.
		OVER	Lit on occurrence of an error due to delayed processing of receive data <Cause> Hardware fault, cable fault, noise, etc.
		AB.IF	Lights on occurrence of an error caused by reception of more than the stipulated number of "1" bits in succession or by short data length of receive data. <Cause> Timing in which the station sending data to the relevant station goes noncontact, short monitoring time, cable fault, noise, etc.
		TIME	Lights on occurrence of a time-out error in data link monitoring. <Cause> Short monitoring time, cable fault, noise, etc.
		DATA	Lights on occurrence of a data error caused by reception of 2 kilobytes or more of faulty data. <Cause> Cable fault, noise, etc.
		UNDER	Lights when the internal processing of the send data is not performed at fixed intervals. <Cause> Hardware fault
		LOOP	Lights on occurrence of a forward/reverse loop error. <Cause> Power OFF at adjacent station, cable break, cable not connected, etc.
		SD	Lit while data is being sent
		RD	Lit while data is being received
(2)	<p>Network number setting switches</p> 	<p>Network number setting (setting on shipment: "1") <Setting range> 1 to 255 Settings outside the 1 to 255 range will cause a setting error (the SW.E LED will light).</p>	
(3)	<p>Group number setting switch</p> 	<p>Group number setting (setting on shipment: "0") <Setting range> 0 to 9 Set "0" if there is no group designation.</p>	
(4)	<p>Station number setting switches</p> 	<p>Station number setting (setting on shipment: 1) <Allowable range> 1 to 64 Settings outside the 1 to 64 range will cause a setting error (the SW.E LED will light).</p>	

3. PART NAMES AND SETTINGS

MELSEC-A


No.	Name	Contents									
(5)	<p>Mode setting switch</p> 	Mode setting (setting on shipment: 0)									
		Mode	Name	Description							
		0	Online (with automatic return)	Automatic return function in the data link							
		1	Not usable								
		2	Offline	Set the self station for noncontact							
		3	Test mode 1	Loop test (forward loop)							
		4	Test mode 2	Loop test (reverse loop)							
		5	Test mode 3	Station to station test (master station)							
		6	Test mode 4	Station to station test (slave station)							
		7	Test mode 5	Self-loopback test							
		8	Test mode 6	Internal self-loopback test							
		9	Test mode 7	Hardware test							
		A	Not usable								
		B	Not usable								
		C	Not usable								
		D	Test mode 8	Network No. check (LED display)							
		E	Test mode 9	Group No. check (LED display)							
F	Test mode 0	Station No. check (LED display)									
(6)	<p>Condition setting switches</p> 	Setting operating conditions (all switches OFF on shipment)									
		SW	Application	OFF	ON						
		1	Network type	PC-to-PC network	Remote I/O network						
		2	Station type	Normal station	Control station						
		3	Parameters used	Common parameters	Default parameters						
		4	Number of stations (effective when SW3 is ON)	OFF	8 stations	OFF	16 stations	ON	32 stations	ON	64 stations
		5		OFF		ON		OFF		ON	
		6	Total number of B/W points (effective when SW3 is ON)	OFF	2k points	OFF	4k points	ON	6k points	ON	8k points
		7		OFF		ON		OFF		ON	
		8	Not used								
(7)	Connector	Connect the fiber-optic cables here. The connection closer to the front face of the module is the "IN" connection and the connection further from the front face is the "OUT" connection.									

* If the settings for (2), (3), (4), (5) and (6) have been changed, reset the ACPU. However, if the mode setting switch (5) is set to one of the modes "D" through "F", it is not necessary to reset the ACPU.

3. PART NAMES AND SETTINGS

MELSEC-A




3.2 Names and Applications of AJ71BR11 Parts



No.	Name	Contents																																	
(1)	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p style="text-align: center; margin: 0;">AJ71BR11</p> <table style="margin: 0; border-collapse: collapse;"> <tr> <td style="padding: 2px;">RUN</td> <td style="padding: 2px;">- POWER</td> </tr> <tr> <td style="padding: 2px;">PC</td> <td style="padding: 2px;">- MNG</td> </tr> <tr> <td style="padding: 2px;">REMOTE</td> <td style="padding: 2px;">- S.MNG</td> </tr> <tr> <td style="padding: 2px;">DUAL</td> <td style="padding: 2px;">- D.LINK</td> </tr> <tr> <td style="padding: 2px;">SW.E</td> <td style="padding: 2px;">- T.PASS</td> </tr> <tr> <td style="padding: 2px;">M/S.E</td> <td style="padding: 2px;">- CPU R/W</td> </tr> <tr> <td style="padding: 2px;">PRM.E</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">CPU R/W</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">OVER</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">ABT</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">TIME</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">DATA</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">UNDER</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">LOOP</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">SD</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="padding: 2px;">RD</td> <td style="padding: 2px;"></td> </tr> </table> </div>	RUN	- POWER	PC	- MNG	REMOTE	- S.MNG	DUAL	- D.LINK	SW.E	- T.PASS	M/S.E	- CPU R/W	PRM.E		CPU R/W		OVER		ABT		TIME		DATA		UNDER		LOOP		SD		RD		RUN	Lit when the module is running normally. Off when a WDT error or SP.UNIT ERROR occurs.
		RUN	- POWER																																
		PC	- MNG																																
		REMOTE	- S.MNG																																
		DUAL	- D.LINK																																
		SW.E	- T.PASS																																
		M/S.E	- CPU R/W																																
		PRM.E																																	
		CPU R/W																																	
		OVER																																	
		ABT																																	
		TIME																																	
		DATA																																	
		UNDER																																	
LOOP																																			
SD																																			
RD																																			
PC	Lit when "PC-to-PC network" is set (SW1 setting = OFF).																																		
REMOTE	Lit when "remote I/O network" is set (SW1 setting = ON).																																		
DUAL	Off all the time.																																		
SW.E	Lit when there is an error in switch settings (2) to (6).																																		
M/S.E	Lit if a station number is duplicated, or there is more than one control station, in the same network.																																		
PRM.E	Lit on occurrence of a common parameters/station specific parameters matching error, or if the parameters received from the subcontrol station differ from those that the self station received from the control station.																																		
POWER	Lit while power is supplied to the module.																																		
MNG	Lit when the module is set as a control station. Off when the module is set as a normal station.																																		
S.MNG	Lights when the module becomes a sub-control station.																																		
D.LINK	Lit while data link operation is in progress.																																		
T.PASS	Lit when the module participates in a baton pass.																																		
CPU R/W	Lit during communication with the CPU.																																		



3. PART NAMES AND SETTINGS

MELSEC-A

No.	Name	Contents	
(1)	LED	CRC	Lit if an error is discovered in the receive data code check. <Cause> Timing in which the station sending data to the relevant station goes noncontact, hardware fault, cable fault, noise, etc.
		OVER	Lit on occurrence of an error due to delayed processing of receive data <Cause> Hardware fault, cable fault, noise, etc.
		AB.IF	Lights on occurrence of an error caused by reception of more than the stipulated number of "1" bits in succession or by short data length of receive data. <Cause> Timing in which the station sending data to the relevant station goes noncontact, short monitoring time, cable fault, noise, etc.
		TIME	Lights on occurrence of a time-out error in data link monitoring. <Cause> Short monitoring time, cable fault, noise, etc.
		DATA	Lights on occurrence of a data error caused by reception of 2 kilobytes or more of faulty data. <Cause> Cable fault, noise, etc.
		UNDER	Lights when the internal processing of the send data is not performed at fixed intervals. <Cause> Hardware fault
		SD	Lit while data is being sent
		RD	Lit while data is being received
(2)	<p>Network number setting switches</p> 	<p>Network number setting (setting on shipment: "1") <Setting range> 1 to 255 Settings outside the 1 to 255 range will cause a setting error (the SW.E LED will light).</p>	
(3)	<p>Group number setting switch</p> 	<p>Group number setting (setting on shipment: "0") <Setting range> 0 to 9 Set "0" if there is no group designation.</p>	
(4)	<p>Station number setting switches</p> 	<p>Station number setting (setting on shipment: 1) <Allowable range> 1 to 64 Settings outside the 1 to 64 range will cause a setting error (the SW.E LED will light).</p>	

3. PART NAMES AND SETTINGS

MELSEC-A

No.	Name	Contents									
(5)	<p>Mode setting switch</p> 	Mode setting (setting on shipment: 0)									
		Mode	Name	Description							
		0	Online (with automatic return)	Automatic return function in the data link							
		1	Not usable								
		2	Offline	Set the self station for noncontact							
		3	Test mode 1	Loop test (forward loop)							
		4	Test mode 2	Loop test (reverse loop)							
		5	Test mode 3	Station to station test (master station)							
		6	Test mode 4	Station to station test (slave station)							
		7	Test mode 5	Self-loopback test							
		8	Test mode 6	Internal self-loopback test							
		9	Test mode 7	Hardware test							
		A	Not usable								
		B	Not usable								
		C	Not usable								
		D	Test mode 8	Network No. check (LED display)							
		E	Test mode 9	Group No. check (LED display)							
F	Test mode 0	Station No. check (LED display)									
(6)	<p>Condition setting switches</p> 	Setting operating conditions (all switches OFF on shipment)									
		SW	Application	OFF	ON						
		1	Network type	PC-to-PC network		Remote I/O network					
		2	Station type	Normal station		Control station					
		3	Parameters used	Common parameters		Default parameters					
		4	Number of stations (effective when SW3 is ON)	OFF	8 stations	OFF	16 stations	ON	32 stations	ON	64 stations
		5		OFF		ON		OFF		ON	
		6	Total number of B/W points (effective when SW3 is ON)	OFF	2k points	OFF	4k points	ON	6k points	ON	8k points
		7		OFF		ON		OFF		ON	
		8	Not used								
(7)	Connector	Connect an F type connector here.									

* The AJ71BR11 is supplied with an F type connector (A6RCON-F).
 If the settings for (2), (3), (4), (5) and (6) have been changed, reset the ACPU.
 However, if the mode setting switch (5) is set to one of the modes "D" through "F", it is not necessary to reset the ACPU.

3. PART NAMES AND SETTINGS

3.3 Cautions on Configuring a Network System

3.3.1 Installation positions of AJ71LP21/AJ71BR11

In order to ensure reliable data transmission, these network modules should not be installed next to the I/O modules which are listed below used with an AC input voltage and load voltage.

Input modules : AX10, AX11, AX20, AX21

Output modules : AY10, AY10A, AY11, AY11A, AY11E, AY13, AY13E, AY22, AY23

3.3.2 Cautions on building a coaxial bus system

(1) Terminal resistors (A6RCON-R75, which will soon be available, or BNC-TMP-05(75)) must be fitted at both ends of the system. These parts are not supplied with the modules and must be purchased separately.

(2) Restrictions on cable length between stations

The length of the coaxial cables used to connect stations is fixed according to the total number of stations, as shown in the table. Use the appropriate lengths.


Use of cable lengths other than those shown in the table may result in communication errors. The total extension length is 500 m (0.31 mile), regardless of the total number of stations.

Total No. of Stations	Cable Length Between Stations
1 to 9	1 to 500 m (0.00062 to 0.31 mile)
10 to 32	1 to 5 m (0.00062 to 0.0031 mile)
	13 to 17 m (0.008 to 0.011 mile)
	25 to 500 m (0.016 to 0.31 mile)

(3) Cautions on wiring

(a) When wiring, a distance of at least 100 mm (3.44 inches) should be kept between the coaxial cables and other power cables and control cables.

(b) In locations subject to a lot of noise, the use of double shielded coaxial cables should be considered.




4. DIMENSIONS

MELSEC-A

4. DIMENSIONS

4.1 AJ71LP21




* Take the bending radius of the cable into account.

Unit: mm (inch)

4. DIMENSIONS

MELSEC-A

4.2 AJ71BR11



Unit: mm (inch)

IMPORTANT

- (1) Design the configuration of a system to provide an external protective or safety interlocking circuit for the PCs.
- (2) The components on the printed circuit boards will be damaged by static electricity, so avoid handling them directly. If it is necessary to handle them take the following precautions.
 - (a) Ground your body and the work bench.
 - (b) Do not touch the conductive areas of the printed circuit board and its electrical parts with non-grounded tools, etc.

Under no circumstances will Mitsubishi Electric be liable or responsible for any consequential damage that may arise as a result of the installation or use of this equipment.

All examples and diagrams shown in this manual are intended only as an aid to understanding the text, not to guarantee operation. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples.

Owing to the very great variety in possible applications of this equipment, you must satisfy yourself as to its suitability for your specific application.

HEADQUARTERS

MITSUBISHI ELECTRIC EUROPE B.V. **EUROPE**
 German Branch
 Gothaer Straße 8
D-40880 Ratingen
 Phone: +49 (0)2102 / 486-0
 Fax: +49 (0)2102 / 486-1120

MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. **CZECH REP.**
 Czech Branch
 Avenir Business Park, Radlická 714/113a
CZ-158 00 Praha 5
 Phone: +420 - 251 551 470
 Fax: +420 - 251-551-471

MITSUBISHI ELECTRIC EUROPE B.V. **FRANCE**
 French Branch
 25, Boulevard des Bouvets
F-92741 Nanterre Cedex
 Phone: +33 (0)1 / 55 68 55 68
 Fax: +33 (0)1 / 55 68 57 57

MITSUBISHI ELECTRIC EUROPE B.V. **IRELAND**
 Irish Branch
 Westgate Business Park, Ballymount
IRL-Dublin 24
 Phone: +353 (0)1 4198800
 Fax: +353 (0)1 4198890

MITSUBISHI ELECTRIC EUROPE B.V. **ITALY**
 Italian Branch
 Viale Colleoni 7
I-20041 Agrate Brianza (MB)
 Phone: +39 039 / 60 53 1
 Fax: +39 039 / 60 53 312

MITSUBISHI ELECTRIC EUROPE B.V. **POLAND**
 Poland Branch
 Krakowska 50
PL-32-083 Balice
 Phone: +48 (0)12 / 630 47 00
 Fax: +48 (0)12 / 630 47 01

MITSUBISHI ELECTRIC EUROPE B.V. **RUSSIA**
 52, bid. 3 Kosmodamianskaya nab 8 floor
RU-115054 Moscow
 Phone: +7 495 721-2070
 Fax: +7 495 721-2071

MITSUBISHI ELECTRIC EUROPE B.V. **SPAIN**
 Spanish Branch
 Carretera de Rubí 76-80
E-08190 Sant Cugat del Vallés (Barcelona)
 Phone: 902 131121 // +34 935653131
 Fax: +34 935891579

MITSUBISHI ELECTRIC EUROPE B.V. **UK**
 UK Branch
 Travellers Lane
UK-Hatfield, Herts. AL10 8XB
 Phone: +44 (0)1707 / 27 61 00
 Fax: +44 (0)1707 / 27 86 95

MITSUBISHI ELECTRIC CORPORATION **JAPAN**
 Office Tower "Z" 14 F
 8-12,1 chome, Harumi Chuo-Ku
Tokyo 104-6212
 Phone: +81 3 622 160 60
 Fax: +81 3 622 160 75

MITSUBISHI ELECTRIC AUTOMATION, Inc. **USA**
 500 Corporate Woods Parkway
Vernon Hills, IL 60061
 Phone: +1 847 478 21 00
 Fax: +1 847 478 22 53

EUROPEAN REPRESENTATIVES

GEVA **AUSTRIA**
 Wiener Straße 89
AT-2500 Baden
 Phone: +43 (0)2252 / 85 55 20
 Fax: +43 (0)2252 / 488 60

TEHNIKON **BELARUS**
 Oktyabrskaya 16/5, Off. 703-711
BY-220030 Minsk
 Phone: +375 (0)17 / 210 46 26
 Fax: +375 (0)17 / 210 46 26

ESCO DRIVES & AUTOMATION **BELGIUM**
 Culliganlaan 3
BE-1831 Diegem
 Phone: +32 (0)2 / 717 64 30
 Fax: +32 (0)2 / 717 64 31

Koning & Hartman b.v. **BELGIUM**
 Woluwelaan 31
BE-1800 Vilvoorde
 Phone: +32 (0)2 / 257 02 40
 Fax: +32 (0)2 / 257 02 49

INEA BH d.o.o. **BOSNIA AND HERZEGOVINA**
 Aleja Lipa 56
BA-71000 Sarajevo
 Phone: +387 (0)33 / 921 164
 Fax: +387 (0)33 / 524 539

AKHNATON **BULGARIA**
 4 Andrej Ljapchev Blvd. Pb 21
BG-1756 Sofia
 Phone: +359 (0)2 / 817 6044
 Fax: +359 (0)2 / 97 44 06 1

INEA CR d.o.o. **CROATIA**
 Losinjska 4 a
HR-10000 Zagreb
 Phone: +385 (0)1 / 36 940 -01 / -02 / -03
 Fax: +385 (0)1 / 36 940 -03

AutoCont C.S. s.r.o. **CZECH REPUBLIC**
 Technologická 374/6
CZ-708 00 Ostrava-Pustkovec
 Phone: +420 595 691 150
 Fax: +420 595 691 199

Beijer Electronics A/S **DENMARK**
 Lykkegårdsvej 17
DK-4000 Roskilde
 Phone: +45 (0)46 / 75 76 66
 Fax: +45 (0)46 / 75 56 26

Beijer Electronics Eesti OÜ **ESTONIA**
 Pärnu mnt.160i
EE-11317 Tallinn
 Phone: +372 (0)6 / 51 81 40
 Fax: +372 (0)6 / 51 81 49

Beijer Electronics OY **FINLAND**
 Peltoie 37
FIN-28400 Ulvila
 Phone: +358 (0)207 / 463 540
 Fax: +358 (0)207 / 463 541

UTEKO **GREECE**
 5, Mavrogenous Str.
GR-18542 Piraeus
 Phone: +30 211 / 1206 900
 Fax: +30 211 / 1206 999

MELTRADE Kft. **HUNGARY**
 Fertő utca 14.
HU-1107 Budapest
 Phone: +36 (0)1 / 431-9726
 Fax: +36 (0)1 / 431-9727

Beijer Electronics SIA **LATVIA**
 Rītausmas iela 23
LV-1058 Rīga
 Phone: +371 (0)784 / 2280
 Fax: +371 (0)784 / 2281

Beijer Electronics UAB **LITHUANIA**
 Savanoriu Pr. 187
LT-02300 Vilnius
 Phone: +370 (0)5 / 232 3101
 Fax: +370 (0)5 / 232 2980

EUROPEAN REPRESENTATIVES

ALFATRADE Ltd. **MALTA**
 99, Paola Hill
Malta- Paola PLA 1702
 Phone: +356 (0)21 / 697 816
 Fax: +356 (0)21 / 697 817

INTEHSIS srl **MOLDOVA**
 bld. Traian 23/1
MD-2060 Kishinev
 Phone: +373 (0)22 / 66 4242
 Fax: +373 (0)22 / 66 4280

HIFLEX AUTOM.TECHNIEK B.V. **NETHERLANDS**
 Wolweverstraat 22
NL-2984 CD Ridderkerk
 Phone: +31 (0)180 - 46 60 04
 Fax: +31 (0)180 - 44 23 55

Koning & Hartman b.v. **NETHERLANDS**
 Haarlerbergweg 21-23
NL-1101 CH Amsterdam
 Phone: +31 (0)20 / 587 76 00
 Fax: +31 (0)20 / 587 76 05

Beijer Electronics AS **NORWAY**
 Postboks 487
NO-3002 Drammen
 Phone: +47 (0)32 / 24 30 00
 Fax: +47 (0)32 / 84 85 77

Fonseca S.A. **PORTUGAL**
 R. João Francisco do Casal 87/89
PT - 3801-997 Aveiro, Esgueira
 Phone: +351 (0)234 / 303 900
 Fax: +351 (0)234 / 303 910

Sirius Trading & Services srl **ROMANIA**
 Aleea Lacul Morii Nr. 3
RO-060841 Bucuresti, Sector 6
 Phone: +40 (0)21 / 430 40 06
 Fax: +40 (0)21 / 430 40 02

Craft Con. & Engineering d.o.o. **SERBIA**
 Bulevar Svetog Cara Konstantina 80-86
SER-18106 Nis
 Phone: +381 (0)18 / 292-24-4/5
 Fax: +381 (0)18 / 292-24-4/5

INEA SR d.o.o. **SERBIA**
 Izletnicka 10
SER-113000 Smederevo
 Phone: +381 (0)26 / 617 163
 Fax: +381 (0)26 / 617 163

SIMAP s.r.o. **SLOVAKIA**
 Jána Derku 1671
SK-911 01 Trenčín
 Phone: +421 (0)32 743 04 72
 Fax: +421 (0)32 743 75 20

PROCONT, spol. s r.o. Prešov **SLOVAKIA**
 Kúpeľná 1/A
SK-080 01 Prešov
 Phone: +421 (0)51 7580 611
 Fax: +421 (0)51 7580 650

INEA d.o.o. **SLOVENIA**
 Stegne 11
SI-1000 Ljubljana
 Phone: +386 (0)1 / 513 8100
 Fax: +386 (0)1 / 513 8170

Beijer Electronics AB **SWEDEN**
 Box 426
SE-20124 Malmö
 Phone: +46 (0)40 / 35 86 00
 Fax: +46 (0)40 / 93 23 01

Omni Ray AG **SWITZERLAND**
 Im Schörl 5
CH-8600 Dübendorf
 Phone: +41 (0)44 / 802 28 80
 Fax: +41 (0)44 / 802 28 28

GTS **TURKEY**
 Bayraktar Bulvarı Nutuk Sok. No:5
TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL
 Phone: +90 (0)216 526 39 90
 Fax: +90 (0)216 526 39 95

CSC Automation Ltd. **UKRAINE**
 4-B, M. Raskovoyi St.
UA-02660 Kiev
 Phone: +380 (0)44 / 494 33 55
 Fax: +380 (0)44 / 494-33-66

EURASIAN REPRESENTATIVES

Kazpromautomatiks Ltd. **KAZAKHSTAN**
 Mustafina Str. 7/2
KAZ-470046 Karaganda
 Phone: +7 7212 / 50 11 50
 Fax: +7 7212 / 50 11 50

MIDDLE EAST REPRESENTATIVES

ILAN & GAVISH Ltd. **ISRAEL**
 24 Shenkar St., Kiryat Arie
IL-49001 Petah-Tiqva
 Phone: +972 (0)3 / 922 18 24
 Fax: +972 (0)3 / 924 0761

TEXEL ELECTRONICS Ltd. **ISRAEL**
 2 Ha'umanut, P.O.B. 6272
IL-42160 Netanya
 Phone: +972 (0)9 / 863 39 80
 Fax: +972 (0)9 / 885 24 30

CEG INTERNATIONAL **LEBANON**
 Cebaco Center/Block A Autostrade DORA
Lebanon - Beirut
 Phone: +961 (0)1 / 240 430
 Fax: +961 (0)1 / 240 438

AFRICAN REPRESENTATIVE

CBI Ltd. **SOUTH AFRICA**
 Private Bag 2016
ZA-1600 Isando
 Phone: +27 (0)11 / 977 0770
 Fax: +27 (0)11 / 977 0761